


DS-520AN Firmware Update Procedure

This document describes how to update the firmware of DS-520AN.

The firmware can be upgraded using the Web browser interface of DS-520AN which can be accessed using the SX Virtual Link utility. Before you start, please make sure that both your PC and DS-520AN are connected to a wired network.

* This document uses the screenshots captured from Windows 8. However, the procedure will be the same if you are using an OS other than Windows 8.


1. Start the SX Virtual Link utility. Right-click the device server on SX Virtual Link's main window and select **Display the Web page** from the menu displayed.




2. The login page is displayed. Enter the password for DS-520AN and click **Login**. (By default, no password is configured to DS-520AN.)




3. After the login, the configuration page is displayed. Click **Firmware Update** under **Maintenance**.



4. In the **Firmware Update** page, click **Browse...** and select the file to be loaded to DS-520AN (DS-520AN.bin file). Check that the file name is displayed in **New firmware** field and click **Update**.



5. The update confirmation message is displayed. Click **OK** to begin the firmware upgrade.



* Do not turn off DS-520AN or close your Web browser while the firmware upgrade is in process.

6. When the login page is displayed, the firmware update is completed. See the bottom left of the page and check the version information is changed.