

SX-590 ファームウェアのアップデート手順

本紙では、SX-590(以降、本製品)のファームウェアアップデート手順について記載しています。
本製品のファームウェアバージョンや、使用するパソコンのOS、使用するWebブラウザやそのバージョンによっては画面上の表示が異なる場合があります。また、一部の説明に対応していない場合がありますがご了承ください。

1. 本製品の内蔵Webページを開きます。
※内蔵Webページを開くには、Webブラウザを起動してアドレスバーに本製品のIPアドレスを入力して、Enterキーを押下します。
2. 本製品のWebページにアクセスするとシステムステータスページが表示されます。左側のメニューから「ログイン」をクリックします。

注意:

- ・「ネットワークへの接続」画面が表示された場合は「接続」をクリックします。その後、警告画面が表示された場合は「詳細設定」をクリックし、表示される「xxxxxxに進む(安全ではありません)」をクリックしてください。
- ・本製品にパスワードが設定されていない場合は、パスワード設定ページが表示されます。

3. パスワードを入力して「ログイン」ボタンをクリックします。
4. システムステータスページに戻ります。左側のメニューに新しい項目が追加されます。Webページ左側の設定メニューから「ファームアップデート」をクリックして「ファームアップデート」ページを表示します。「新しいファームウェア」の右のボタンをクリックして、ダウンロードしたファームウェア(SX-590.bin)を指定します。
5. 「新しいファームウェア」フィールドに正しいファイル名が表示されていることを確認して「アップデート」をクリックします。
6. アップデート確認画面で「OK」をクリックすると、ファームウェアのアップデートが開始されます。ファームウェアのアップデートが完了するまで、しばらくお待ちください。

注意:

ファームウェアのアップデート中は、本製品の電源を切ったり、Webブラウザを終了したりしないでください。

7. ファームウェアのアップデートを行った本製品のシステムステータスページが表示されたら、ファームウェアのアップデートは完了です。Webページの左下に表示されているバージョン表記を確認して、ファームウェアが最新バージョンに更新されていることを確認してください。

サイレックス・テクノロジー株式会社

URL: www.silex.jp

【製品に関するお問合せ】

E-mail: support@silex.jp

SX-590 Firmware Update Procedure

This document describes how to update the firmware of SX-590.

The screen display may vary depending on the SX-590 firmware version, or the operating system, Web browser and its version of the PC. Some instructions may not be applicable.

1. Access the internal Web page of SX-590. To access the internal Web page, open your Web browser and enter the IP address of SX-590 into the address bar and press Enter key.
2. When you have connected to the SX-590, you will get the **System Status** page. Click **Login** on the left side of the screen.

NOTE:

- If the **Connect to a network** screen appears, click **Connect**. If a warning screen appears then, click **Advanced** and click **Continue to xxxxxx(unsafe)**.
- When the password is not configured to SX-590, the **Password Configuration** page is displayed.

3. Enter the password for the unit and click **Login**.
4. You will return to the **System Status** page, but new options will be listed on the left side of the screen. In the Web page, click **Firmware Update** on the left menu. In the **Firmware Update** page, click the button to the right of **New firmware** to specify the firmware update file that you have downloaded into your computer(SX-590.bin file).
5. Check the correct file name is displayed in **New firmware** field and click **Update**.
6. The update confirmation message is displayed. Click **OK** to begin the firmware upgrade.

NOTE:

Do not turn off SX-590 or close your Web browser while the firmware upgrade is in process.

7. When the **System Status** page is displayed, the firmware update is completed. See the bottom left of the page and check the version information is changed.

Silex Technology America, Inc.

<https://www.silextechnology.com/>

Technical Support: support@silexamerica.com

Sales: sales@silexamerica.com

Silex Technology Europe GmbH

<https://www.silextechnology.com/>

Email: contact@silexeurope.com

WA104970XE