


Firmware Update Procedure

This document describes how to upgrade the firmware of BR-300AN.


The firmware can be updated using the Web browser interface of BR-300AN.

* In this document, Windows 7 is used as an example. However, the procedure will be the same if you are using an OS other than Windows 7.


- 1** Connect BR-300AN to the PC using the network cable that came with BR-300AN.



- 2** Connect the AC adaptor to BR-300AN, and the AC adaptor's plug to an electrical outlet.




- 3** When the POWER LED (at the top) turns ON, press and hold the push switch (at the front). Release the push switch when WLAN LED and STATUS LED start to blink together (it may take 20sec until blinking). BR-300AN will start running in the **Configuration Mode** then. Now you can upgrade the firmware of BR-300AN from the PC that has been connected to BR-300AN via a network cable.




* If wireless LAN is enabled on your PC, please disable it.


- 4** Start your Web browser (e.g. Internet Explorer, Safari, etc.) from the PC and then the Web interface of BR-300AN will be displayed. Click **Firmware Update**.



- 5** Firmware Update page is displayed. Click **Browse** to select the firmware update file (**BR-300AN.bin**). Check that the file name is displayed at **New firmware** field and click **Update**.



- 6** Click **OK** to the confirmation message. The firmware update will begin. All LEDs on top of BR-300AN turn ON while the firmware update is in process.



* Do not turn off BR-300AN or close your Web browser while the firmware update is in process.

- 7** When the LED status changed from above, turn off BR-300AN by unplugging AC adaptor from the electrical outlet. The firmware update has been completed now.